

## Wurlitzer Model 200 L.E.D MOD

### Tools Needed

Drill, 5/16<sup>th</sup> drill bit

Soldering iron/solder

\*Always unplug amplifier before servicing. **DO NOT JUST TURN OFF!!**

1. Remove existing Neon Bulb from hole and remove leads from terminal strip.
2. Drill out existing hole to 5/16<sup>th</sup>.
3. Remove L.E.D holder from backing PCB by pulling out.
4. Put L.E.D holder thru hole and install washer and screw and tighten.
5. Push L.E.D Rubber stopper into L.E.D holder
6. Solder Red wire to cathode side of Power supply Rectifier, (diode) D-3  
(This is the side with the band on it) Look for D-3 on the Board diagram on our free online 200 manual)
7. Solder the Black wire to any ground point. (Yellow and Red transformer wire is good)
8. This completes your led Mod.