

VintageVibe.com

Spinnet organ line out kit

1. The small box with the 3 colored wires goes to the back of your organ. Find a spot close to the original speaker wires and with the hardware included secure it to the organ.
2. Connect the bigger box to a location in front in which you are comfortable with and it is within reach.
3. Have a soldering iron ready and a pair of cutters,
4. Cut the green wire off of the speaker connection and solder the green wire from the small box to the green wire that was going to the speaker.
5. Next connect the red wire from the little box to the green wire that comes from the amplifier that went to the positive speaker terminal that you removed.
6. Now solder the black wire to the black wire on the speaker terminal (negative side).
7. Connect stereo ¼ inch cable to both boxes and you are ready to go.
8. Thanks for choosing vintage vibe parts and kits!!!!