

# VintageVibe.com

## Wurlitzer 200A L.E.D Modification

The purpose of this mod is to eliminate the possibility of stray AC entering the audio path due to AC wires next to Audio wires. This L.E.D runs on DC it will last longer burn brighter and never produce hum.

1. Remove old Neon lamp.
2. Drill out existing hole in metal angle plate to 5/16th of an inch. The same hole as old neon was mounted to.
3. Remove rubber stopper from back of L.E.D and place assembly thru the hole. Screw on nut with washer and push rubber stopper back into assembly.
4. Take the "Red" wire and solder it to the +22.5 volts pin on your amplifier which also says TP for test point, it is in the upper right hand corner next to the big filter caps.
5. Next take your "Black" wire and solder it to any ground point on the board. There are many ground points. Pick and pin with a "G" next to it.
6. This completes the installation of your Mod.

Thank you for choosing Vintage Vibe, We truly appreciate it.