



Wurlitzer Reed Length Chart

Tools needed

File, solder, soldering iron, cutter snips

1. Reed should be measured and marked for cutting to the inside of the line, since these reeds were traced around the outside.
2. Always cut square and deburr rough edges of the reed before adding solder.
3. Always shape the lead into a pyramid as to achieve proper oscillation and tone.