VintageVibe.com

Wurlitzer 200A Fuse Mod

1. Remove Amplifier board screws, turn amp over and unsolder pigtail fuse connections, Remove the fuses completely.
2. Turn amp over and put one side of fuse mod into one hole and solder closed, repeat with the other side.
3. Do this with both of the new fuses, when complete, glue new terminals to a secure location on the metal plate next to the amp using, epoxy, goop or silicone. Now, if and when a fuse blows just replace with the same fuse. 1 ½ amp fast blow 250 volt. Keep spare fuses taped to the inside of the Wurlitzer.

THANK YOU FOR CHOOSING VINTAGE VIBE!!!!